



Acer Aspire One D150 Webcam Replacement

Written By: Minimac13



Step 1 — Webcam



- Unscrew the two screws on the top of the screen

Step 2




- ⚠ Gently pull the plastic part.

Step 3



- Remove the connection with a screwdriver .

Step 4



- Simply pull the webcam out.

To reassemble your device, follow these instructions in reverse order.